PENINSULA WALLPAPER

SPEC & CARE SHEET
NOVEMBER 2026

NATURAL COLLECTION

Alabaster Cork

CORK WALLCOVERING · N178NQ8390 · ALABASTER



A soft alabaster-white natural cork, flecked with warm copper.

TEXTURE DEPTH	FINE FLECKS
NATURAL VARIATION	NOTICEABLE
SHEEN	LOW

COMPOSITION	100% cork on paper backing
WIDTH	0.91m (36")
ROLL LENGTH	10m
COVERAGE	≈ 9.1m² per roll
PATTERN REPEAT	Random, no repeat
HANGING	Non-reverse hang (every length hung the same way up)
APPLICATION	Paste the wall only (or paste the back of the paper and apply it to the wall instead); double cut required
FIRE RATING	Group 2 — tested to AS ISO 9705-2003 for the Building Code of Australia (wall and ceiling linings); specific extinction area under 250 m²/kg
LEAD TIME	Allow 3–5 weeks · subject to mill stock
INSTALLATION NOTES	Double cut required. Professional installation recommended.

CARE

- Natural wallcoverings aren't stain-repellent treated, so treat the surface gently.
- Dust occasionally with a vacuum on a soft brush attachment.
- Trying something new? Test it on a hidden spot first, and if it isn't working, stop and contact us.
- Blot any spill straight away with a clean, dry, white cloth. Dab lightly, never rub.
- Don't use water, sprays or detergents on the surface.

NATURAL MATERIALS

- Colour, texture, weave and shading vary naturally between rolls — part of the material's character, not a defect.
- Order enough for the whole job from the same dye lot in a single order, and check each roll against the last before hanging.
- Hang every length the same way up (non-reverse hang) so the weave runs consistently across the wall.
- Sales of natural wallcoverings are final and non-refundable.

INSTALLATION GUIDE

01 Prepare the walls first — clean, dry, smooth, and primed. Natural wallcoverings telegraph any imperfection beneath them.

02 Paste the wall only — there's no need to paste the back. Alternatively, paste the back of the paper and apply it to the wall.

03 Double cut required: overlap adjoining drops slightly, cut through both layers with a sharp blade against a straight edge, then remove the offcuts for a clean, tight seam.

04 Work from a single batch and check each roll against the last before hanging.

05 Keep adhesive off the face. If any gets on the surface, gently dab with a damp microfibre cloth — never rub.

06 Professional installation is strongly recommended.

> **Professional installation recommended.** Peninsula Wallpaper installs across the Mornington Peninsula, Bayside Melbourne and the Gold Coast — email Projects@peninsulawallpaper.com.au to arrange a measure and quote.